



Gigabit Ethernet Adapter

User's Guide

Version 1.0

PN# 1907GA1200T6380

This User's Guide contains important information regarding the installation of your adapter card. Please read it completely before beginning installation.

For future reference, record the serial number of your network adapter in the space below :

SERIAL number

The serial number is located on the face of the card.

Amer.com

7259 Bryan Dairy Road, Largo, FL 33777

© Amer.com Corp., 1997-2002 All rights reserved.
No part of this publication may be reproduced in any form or by any means or used to make any derivative such as translation, transformation, or adaptation without permission from Amer.com, as stipulated by the United States Copyright Act of 1976.

Amer.com reserves the right to make changes to this document and the products which it describes without notice. Amer.com shall not be liable for technical or editorial errors or omissions made herein; nor for incidental or consequential damages resulting from the furnishing, performance, or use of this material.

Amer.com is a registered trademark of Amer.com. All other trademarks and trade names are properties of their owners.

FCC Class B Certification Statement

Model C1110-32 FCC Class B

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- . Reorient or relocate the receiving antenna.

- . Increase the separation between the equipment and receiver.

- . Connect the equipment into an outlet on a circuit different from that to which the receiver is connected to.

- . Consult the dealer or an experienced radio/TV technician for help.

Shielded interface cables must be used in order to comply with emission limits. You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment. For more information please contact the Federal Communication Commission.

CE Mark Class B Statement In a domestic environment, this product may cause radio interference in which case the user may be required to take adequate measures.

INTRODUCTION

Thank you for choosing the 10/100/1000Mbps Gigabit Ethernet Card for 32-bit PCI Bus-equipped personal computers. The 32-bit PCI 10/100/1000Mbps Gigabit Ethernet Card is ideal for speeding up data transfers for network servers and other computers, such as those used for video-conferencing, that send and/or receive large amounts of data. The 32-bit PCI 10/100/1000Mbps Gigabit Ethernet Card also includes the newest networking technologies, such as multicasting support, that use network bandwidth more efficiently and further help the card maximize data throughput.

Features

- ◆ IEEE 802.3, 802.3u and 802.3ab compliant
- ◆ Support 32-bit 33/66Mhz PCI Local Bus Master high-speed operation of Rev.2.1/2.2 specification
- ◆ Plug-and-Play installation
- ◆ One RJ-45 connector: Auto detection of 10Mbps Ethernet, 100Mbps Fast Ethernet and 1000Mbps Gigabit Ethernet & Auto MDI-X

- ◆ Supports IEEE802.1Q VLAN tagging
- ◆ Supports 10/100/1000Mbps Auto-negotiation operation
- ◆ Full Duplex support for 10/100/1000Mb/s data rates
- ◆ Auto MDI-II/MDI-X crossover for all three speeds
- ◆ Built-in FIFO (8K/64K) buffers reduces overhead of memory transfers
- ◆ 802.3x Full duplex flow control, including automatic transmission of Pause frames based on Rx FIFO thresholds
- ◆ Two LED indicators for easy diagnostic

Gigabit Ethernet Technology

Gigabit Ethernet is an extension of IEEE 802.3 Ethernet utilizing the same packet structure, format, and support for CSMA/CD protocol, full duplex, and management objects, but with a tenfold increase in theoretical throughput over 100Mbps Fast Ethernet and a one hundred-fold increase over 10Mbps Ethernet. Since it is compatible with all 10Mbps and 100Mbps Ethernet environments, Gigabit Ethernet

provides a straightforward upgrade without wasting a company's existing investment in hardware, software, and trained personnel.

The increased speed and extra bandwidth offered by Gigabit Ethernet is essential to coping with the network bottlenecks that frequently develop as computers and their busses get faster and more users use applications that generate more traffic. Upgrading key components, such as your backbone and servers to Gigabit Ethernet can greatly improve network response times as well as significantly speed up the traffic between your subnets.

Gigabit Ethernet enables Twisted-Pair cable connections to support video conferencing, complex imaging, and similar data-intensive applications. Likewise, since data transfers occur 10 times faster than Fast Ethernet, servers outfitted with Gigabit Ethernet NIC's are able to perform 10 times the number of operations in the same amount of time.

Fast Ethernet Technology

The growing importance of LANs and the increasing complexity of desktop computing applications are fueling the need for high performance networks. A number of high-speed LAN technologies have been proposed to provide greater bandwidth and improve client/server response times. Among them, 100BASE-T (Fast Ethernet) provides a non-disruptive, smooth evolution from the current 10BASE-T technology. The non-disruptive and smooth evolution nature, and the dominating potential market base, virtually guarantee cost effective and high performance Fast Ethernet solutions in the years to come.

100Mbps Fast Ethernet is a new standard specified by the IEEE 802.3 LAN committee. It is an extension of the 10Mbps Ethernet standard with the ability to transmit and receive data at 100Mbps, while maintaining the CSMA/CD Ethernet protocol. Since the 100Mbps Fast Ethernet is compatible with all other 10Mbps Ethernet environments, it provides a straightforward upgrade and takes advantage of the existing investment in hardware, software, and personnel training.

UNPACKING AND INSTALLATION

This chapter provides unpacking and installation information for the 32-bit PCI 10/100/1000Mbps Gigabit Ethernet Card.

Unpacking

CAUTION: *Under ordinary circumstances, the 32-bit PCI 10/100/1000Mbps NWay Gigabit Ethernet Card will not be affected by static charge as may be received through your body during handling of the unit. However, there are special circumstances where you may carry an extraordinarily high static charge, and possibly damage the card and/or your computer. It is good practice to eliminate all static electricity by touching a ground (an unpainted metal area of your computer chassis, for example) before performing any installations.*

Open the shipping carton and carefully remove all items. In addition to this User's Guide, ascertain that you have:

- One 32-bit PCI 10/100/1000Mbps Gigabit Ethernet Card.
- One Driver Diskette
- This User's Guide.

If any item is found missing or damaged, please contact your local reseller for replacement.

Installing the Gigabit Ethernet Card

1. Shut down the computer, unplugs its power cord, and remove the chassis cover.
2. Insert the contact edge of the Gigabit Ethernet card into the connector of any available PCI Bus Master expansion slot. Press the card firmly into the connector such that the card's contacts are fully seated in the connector, this card can put either in 32-bit or 64-bit PCI slot, but it is recommended that the card to put in the 64-bit PCI slot to have the maximum performance.
3. Install the bracket screw and secure the card to the computer chassis.
4. Cover the computer's chassis.

5. Switch computer power on. If the BIOS section of your computer's boot program is Plug-and-Play compliant, then at power-up the BIOS will automatically configure any newly installed the Gigabit Ethernet Card.

NOTE: *Due to a fault in some Plug-n-Play BIOS programs, it happens occasionally that a newly installed adapter is assigned an Interrupt Number which is already assigned to another device. In such a case, the conflict of Interrupt Number will cause faults in the behavior of both devices. Then it is necessary to run the CMOS Setup utility, and manually assign a non-conflicting Interrupt Number.*

Connecting the Network Cable

Four pair of Cat.5 UTP or STP cable with RJ-45 connector is required for the 32-bit PCI 10/100/1000Mbps Gigabit Ethernet Card. You can use standard or crossover cable to connect the switch MDI-X or MDI-II port, because the 32-bit PCI 10/100/1000Mbps Gigabit Ethernet Card will adjust the correct signal automatically.

Software Installation

Before you connect the 32-bit PCI 10/100/1000Mbps Gigabit Ethernet Card to the network, you have to install the network driver first. The driver for each networking operating system is under a separate directory. A HELPME.COM file under root directory lists the information and detailed installation procedure of all the available drivers.

LED INDICATORS

Two LED indicators: Link, Activity.

Link Indicator

This indicator lights green when the Gigabit Card is connects to 10/100/1000Mbps Gigabit Ethernet Network.

Activity Indicator (ACT)

This indicator blinking green will be transmitting or received data on the network.

TECHNICAL SPECIFICATIONS

General	
Standards	IEEE 802.3 10Base-T Ethernet IEEE 802.3u 100Base-TX Fast Ethernet IEEE 802.3ab 1000Base-T Gigabit Ethernet IEEE 802.3x Flow Control
Protocol	CSMA/CD
Data Transfer Rate	Ethernet: 10Mbps (half), 20Mbps (full) Fast Ethernet: 100Mbps (half), 200Mbps (full) Gigabit Ethernet: 1000Mbps (half), 2000Mbps (full)
Topology	Star
Network Cables	Ethernet: 2-pair UTP Cat. 3,4,5 , EIA/TIA- 568 STP Fast Ethernet: 2-pair UTP Cat. 5, EIA/TIA-568 STP Gigabit Ethernet: 4-pair UTP Cat.5, EIA/TIA-568 STP
LED Indicator	Link, Activity
RJ-45 Port	Auto MDI-II/MDI-X port
Physical and Environmental	
Power Consumption	4.5 watts. (max.)
Temperature	Operating: -10° ~ 40° C, Storage: -10° ~ 70° C
Humidity	Operating: 10% ~ 90%, Storage: 5% ~ 90%
Dimensions	59 x 120 x 15mm (W x D x H)
EMI:	FCC Class B, CE Mark B, VCCI-B

Amer.com Warranty Policy

Limited Lifetime Warranty

In the event of a defect in quality or workmanship, Amer.com will repair or replace any hardware product sold by Amer.com with new or reconditioned parts free of charge in North America for a limited lifetime period unless otherwise specified on the sales invoice from the date of original purchase. All removed parts become the property of Amer.com. All replaced parts assume the original warranty.

This warranty is extended only to the original purchaser. Proof of purchase will be required before warranty service is provided.

This warranty covers only failures due to defects in quality or workmanship that occur during normal use. It does not cover damage that occurs in shipment, electrical storms, floods, dropped or other acts of nature.

This warranty also does not cover any failure that results from accident, misuse, abuse, neglect, mishandling, misapplication, alteration, faulty installation, modification, computer virus,

improperly installed or faulty software, or service by anyone other than an Amer.com Service Technician. If there is evidence that the failure was due to user negligence, Amer.com has the right to void this warranty and or charge normal service rates for the subject repair.

The limited warranty covers a one (1) year period from date of purchase on Power Supplies, AC Adapters & Fans, after the 1 year a cost for replacement is applied to all products requiring such parts.

Amer.com is not responsible for any type of data loss on hard drive or other storage devices.

Warranty Service can be obtained during the warranty period by shipping, freight prepaid, or delivering the product to Amer.com in either the original package or a similar package providing an equal degree of protection. Amer.com will perform the required service and return the unit to the user (freight prepaid), if applicable, via the same mode (i.e. ground, air, etc.)

Limits and Expectations

There are no express warranties except as listed above.

Network products by Amer.com shall not be liable for incidental or consequential damages resulting from the use of this product. Any future upgrades, including (but not limited to) hardware and software are not covered by this limited warranty. If a hardware problem with this product develops during the warranty period, you may contact the Amer.com Service Center at:

Telephone (727) 549-0772
Facsimile (727) 549-0992

Service Center
Amer.com
7259 Bryan Dairy Road
Largo, Florida
33777
U.S.A.